



4200R SERIES RIM DEVICE INSTALLATION INSTRUCTIONS FOR LHR DOOR

E53-5C50RS212
10/06-00



4200R SERIES RIM DEVICE INSTALLATION INSTRUCTIONS FOR RHR DOOR

