# 5300/5500 DOOR CLOSER MODELS

# REGULAR ARM INSTALLATION - PULL SIDE NON-HOLD OPEN AND HOLD OPEN APPLICATIONS

Opening	Dim. A	Dim. B
To 100°	7-1/2" [190.5]	13" [330.2]
101° to 130°	6" [152.4]	11-1/2" [292.1]
Over 131°	4-1/2" [114.3]	10" [254]


Dim. C		
MIN. CEILING CLEARANCE NON-HOLD OPEN	1-7/8" [47.6]	
MIN. CEILING CLEARANCE HOLD OPEN	2" [50.8]	
MIN. FACE HEIGHT NON-HOLD OPEN	1-5/8" [41.3]	
MIN. FACE HEIGHT HOLD OPEN	1-3/4" [44.5]	

Dim. D	
MIN. RAIL TO MOUNT CLOSER	2-1/4" [57.2]
MIN. RAIL TO BOTTOM OF DUST CAP WITH STREAMLINE COVER - 5300 SERIES	3" [76.2]
MIN. RAIL TO BOTTOM OF FULL COVER - 5500 SERIES	3-3/8" [85.7]

REV. 0

**TEMPLATE: 539301,** 

01-31-12



## NOTES:

- 1. DRAWING IS NOT TO SCALE.
- 2. DIMENSIONS IN INCHES IMM1.
- 3. RIGHT HAND DOOR SHOWN. FOR LEFT HAND DOOR REVERSE IMAGE.
- 4. DIMENSIONS BASED ON 4-1/2" X 4-1/2" BUTT HINGES.
- 5. DOOR SWING MAY BE ALTERED DUE TO OTHER LIMITING CONDITIONS.
- 6. CAUTION: SEX NUTS MAY BE REQUIRED FOR UNREINFORCED DOORS OR COMPOSITE FIRE DOORS. CONSULT MANUFACTURER'S RECOMMENDATIONS.
- 7. HOLD OPEN ARMS CAN NOT BE USED ON LABELED FIRE DOORS.
- 8. ALWAYS CHECK PDQ WEBSITE FOR THE MOST RECENT REVISION AT WWW.PDQLOCKS.COM.

#### **MACHINE SCREWS:**

USE #7 OR 13/64" [5.1] DRILL AND 1/4-20 TAP

## WOOD DOOR/FRAME SCREWS:

USE 5/32" [4] DRILL

#### **SEX NUTS:**

USE 3/8" [9.5] DRILL (CLOSER TO DOOR)



www.pdglocks.com